Acer LCD Monitor Quick Start Guide (QSG)

English

Important safety instructions

Please read the following instructions carefully.

1 To clean the LCD monitor screen:
   - Turn off the LCD monitor and unplug the power cord.
   - Spray a non-solvent cleaning solution onto a rag and clean the screen gently.
2 Do not place the LCD monitor near a window. Exposing the monitor to rain, moisture or sunlight can severely damage it.
3 Do not apply pressure to the LCD screen. Excessive pressure may cause permanent damage to the display.
4 Do not remove the cover or attempt to service this unit yourself. An authorized technician should perform servicing of any nature.
5 Store the LCD monitor in a room with a temperature of -20° to 60° C (-4° to140° F). Storing the LCD monitor outside this range may result in permanent damage.
6 Immediately unplug your monitor and call an authorized technician if any of the following circumstances occur:
   - Monitor-to-PC signal cable is frayed or damaged.
   - Liquid spills onto the LCD monitor or the monitor is exposed to rain.
   - The LCD monitor or case is damaged.

Package contents

LCD monitor	AC Power cable	DVI cable (Optional)	VGA cable	HDMI cable (Optional)	AC Adapter	User guide	Quick start guide



Attaching the monitor to the base

1 Remove the monitor base from the packaging and place it on a stable and level workspace.
2 Remove the monitor from the packaging.
3 Attach the monitor stand arm to the base.
   - Ensure that the base is locked onto the monitor stand arm. (for selected models)
   - Secure the base to the monitor stand arm by turning the white screw using the integrated tab or a suitable coin. (for selected models)

Connecting your monitor to a computer

1 Turn off your computer and unplug your computer's power cord.
2 Connect the signal cable to the VGA and/or DVI-D (optional) and/or HDMI (optional) input socket of the monitor, and the VGA and/or DVI-D (optional) and/or HDMI (optional) output socket of the graphics card on the computer. Then tighten the thumbscrews on the signal cable connector.
3 Connect one end of the adapter to the monitor and the other end to a properly grounded, AC outlet.
4 Plug the power cords of your computer and your monitor into a nearby electrical outlet.



Panel controls

No.	Item	Description
1	Power button / indicator	Turns the monitor on/off. Blue indicates power on. Blinking blue indicates standby / power saving mode.
2	< / > button	Press the < / > button to navigate to the desired function or to change the settings of the current function.
3	Menu / Enter button	Press to view the OSD menu. Press it again to enter a selection in the OSD menu.
4	Auto / Exit button	• When the OSD menu is active, press this button to exit the OSD menu. • When the OSD menu is inactive, press this button to activate the Auto Adjustment function.
5	Empowering Key	Press this button to open the Acer eColor Management OSD and access the scenario modes.



Downloaded from www.Manualslib.com manuals search engine

English

Regulations and safety notices

FCC notices

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful Interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

CE declaration of conformity

Hereby, Acer Inc., declares that this LCD monitor is in compliance with the essential requirements and other relevant provisions of EMC Directive 2004/108/EC, Low Voltage Directive 2006/95/EC, and RoHS Directive 2002/95/EC and Directive 2009/125/EC with regard to establishing a framework for the setting of ecodesign requirements for energy-related product.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with EMC regulations.

Notice: Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user authority, which is granted by the Federal Communications Commission, to operate this product.

Operation conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian users

This Class B digital apparatus complies with Canadian ICES-003. Remarque a l'intention des utilisateurs canadiens Cet appareil numerique de la classe B est conforme a la norme NMB-003 du Canada.

Disposal of waste equipment by user in private household in the European Union

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over it a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information abut where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Downloaded from www.Manualslib.com manuals search engine